MT-MA1401 Manual Instruction

Function Description

Play Mode: Bluetooth/FM/USB/SD/Auxiliary Input
Power Adapter: Input: AC110~230V 50/60Hz Output: DC 9V 2.5A

Button Instruction on Panel:

1. **----ON/OFF/Standby**

2.

----Shift Key In playback Mode/Battery Charging Status

3. 

----EQ Audio effect mold choosing button/MY EQ Custom Set (All play model are available)

4.

----Into Clock set button/query the current time

5.

----Review Alarm/Alarm set button

6. **---- Previous Button (Reset button, support different operation function in different play mode).**

7. **----Pause/Play (Reset, support different operation function in different play mode)**

8. **----Next Button (Reset, support different operation function in different play mode)**

9.

---Store Button (Work under FM play mode)

10

----Repeat Button (Work under USB/SD Play Mode)

11.

---Master VOL reduce/decrease adjust Button("—" is decrease, "+"is increase, all play mode are fit for this operation)

ON/OFF Operation Instruction

1. Plug standard adapter into power source AC 100-240V 50/60Hz, Plug DC into the DC IN port of the back of machine, press button ON, the machine will be into standby mode, and LCD showing system time and date. Press button step into ON working mode. Long press **button, then will show POWER OFF to close down.**

Bluetooth Mode

1. Short press

button switch to Bluetooth Mode,(Now Bluetooth automatic proceed to research and match/reconnecting Pairing. If have connected with this product, then will automatic reconnecting. If connect successful, showing Pairing Success, and will show Connected when playing music).

2. When open Bluetooth and connecting in mobile phone or other terminals, research the name of MT-1401B and connect.

3. After connecting, you can play music in mobile phone and other Bluetooth terminal, and the music can be transferred to MT-1401B playing via Bluetooth.

4. Short press **button, then pause, press again, then continue playing. Long press it, then will disconnect with Bluetooth, and automatically research Bluetooth terminal again.**

5. Short press **button, control connecting mobile or other terminal to play previous song.**

6. Short press **button, control connecting mobile or other terminal to play next song.**

7. Long press **button, remove the memory in connected**

Bluetooth terminal

FM Mode Instruction

1. Short press

button, switch to FM playing mode, now LCD will display the current FM frequency.

2. Short press **button, adjust toward to the lower frequency of 0.05MHz, if long press, it will automatically research towards to the lower frequency. When research a station, then it will be stop to play.**

3. Short press **button, adjust toward to the higher frequency of 0.05MHz, if long press, it will automatically research towards to the higher frequency. When research a station, then it will be stop to play.**

4. The FM frequency: 88-108MHZ

A) The Operation of storing current favorite station

1. Long press

button, through **button or** **button, choose the required position for storage (you can also preset store CH00-CH19) optional. After that, press** **button to confirm, then done.**

B) The operation of playing stored station

1. Short press

button, through

or **button, choose the position of stored favorite station (you can also preset recall 00-19) optional, then press** **button to confirm.**

The Operation of USB playing mode (it will work after plugging U disc)

1.Short press

button, then switch to USB play mode.

2.Plug a MP3/WMA stored U disc to USB slot, then the machine will automatic play music, and LCD will show the quantity of music file/current playing music/playing time.

3.Short press **button, play previous song**

4.Short press **button, play next song.**

5.Short press button **, pause playing music, if press again, it will continue playing.**

6.Short press

button, ten repeat current song.(the available cycle modes: ALL/FOL/ONE/RAN).

7. Mobile Phone Charger
Plug a USB Cable to the USB slot, and the other end connect with Android/Ipho ne4S/Iphone 5S Mobile phone, then LCD on the phone will show charging. (Mac hine should be working). Charger Output: 5V 1A.

The Operation of SD playing mode (it will work after plugging SD card)

1.Short press

button, then it will switch to SD playing mode.

2.Plug a MP3/WMA stored SD card to SD slot, then the machine will automatic play music, and LCD will show the quantity of music file/current playing

3. Short press **button, play previous song**

4. Short press **button, play next song.**

5. Short press **button, pause playing music, if press again, it will continue playing.**

6. Short press

button, ten repeat current song.(the available cycle modes: ALL/FOL/ONE/RAN).

The Operation of Auxiliary Input

1. Short press

button, then it will switch to Auxiliary Input playing mode, plug 3.5mm audio cable into AUX IN slot on the machine, and the other end is connecting with other audio source and playing.

The Operation of Time Setting

1. Long press

button enter into the menu for time setting, the setting order is: set time/set date. (Like: need to set system time is 17:30 8th-Nov-2014, then you can long press

button into set time menu, through **up button or** **down button to 17 clock, press** **button to confirm hour, set minutes after that, just press through** **up button or** **down button to 30minutes, press** **button to confirm, skip to set date, through** **up button or** **down button to 8th**

press **button date to confirm it then skip to month setting, through** **up button or** **down button adjust to Nov. Then press** **button to confirm it, then skip to Year setting after confirming month, you can do through** **up button or** **down button adjust to 2014, then press** **button to confirm year. After that, it would prompt Time saved and automatic exit& store time setting, then back to playing mode. (It will work under playing mode).**

2. Short press **button, you can check current system time under playing mode.**

The Operation of Alarm Setting

The order of alarm setting: long press alarm button into alarm setting—alarm1/alarm2 setup option—set the time of alarm—set the ringing mode of alarm (Daily/Once, Once need choose setting the date of alarm)— set the VOL of alarm. Such as: want to set alarm1:20:30 20th-Jan-2015, ringing 20 times, the method is following:

Long press **button into alarm setting, through** **or** **button, choose alarm1 setup. Press** **button to confirm setting alarm1, after that, you can separately set on time is 20:30 through** **or** **button and** **button, through** **or** **and** **button to**

choose “Once” or “Daily” for the ringing way. Then you can through **or** **and** **button to set Date is 20-01-2015, after pressing** **button, you can through** **or** **and** **button to set Volume is 20. Pressing to confirm, and choose Alarm On.**

Pressing **button to prompt Alarm Saved finish setting. (it is same to set Alarm2 and Daily). When the alarm is ringing, press** **button to close alarm.**

Battery Display

When plugging DC power, the built-in battery will be charged, when charging, LCD display will show the charge status of battery. After battery has charged full, LCD is showing full and the machine will automatically quit charging (working in standby). In any playback mode, long press MODE **key, we can view the current of the battery information, when using the battery (no power adapter), standby mode can show the current capacity of the battery, in any mode, long press** MODE **key can check the electric quantity.**

The Choice of EQ Sound

Whatever the playing mode, you can through short pressing EQ button to switch the audio sound style of music you enjoy.
(normal-classic-jazz-pop=rock-bass-treble-my EQ)

The Custom Setting for My EQ

Long press EQ button, entering into MY EQ Setting, separately

through **or** **and** **button as per personal interests of high-low sound to choose Bass and Treble output, can be adjusted respectively by±14Db. After setting over, you can choose my EQ in the option of EQ sound, then you can enjoy the music style you like.**